



Button Making 101


1. Cut out 2 ¼" image on glass plate with circle cutter. Move the cutter clockwise.




2. Slide button maker plate to the right, position the button back with the crooked side of the button back facing you.
3. Place button back in slot as shown below.





4. Slide button maker plate to the left and assemble button top, image, and mylar circle.



5. Insert button top face-up, then image, and top with mylar circle.



6. Slide button maker plate to the right so that the button front is underneath the handle and press the handle down to “pick up” the button front.



7. Slide button maker plate to the left and press the handle down to pick up the button back and connect it to the button front. Pull handle up and push plate to the right to get your new button!

